



Electric Heated Insoles with USB interface

SKU: 2623

Rated Voltage/Current: 5V/2A

Size: ALL SIZE

Temperature: 40-50°C (depends on the environment)

EN Electric Heated Insoles with USB interface. User manual.

The design of the power cord is one divided into two for this product, with two legs separated and easy to use. The specific steps are as follows:

1. Put insoles into each shoe.
2. Put the DC plugs on the insoles separately into the power cord.
3. Connect the USB plug on the power cord to the power supply.

SAFETY PRECAUTIONS

- The insole is heated after electrified, and it will reach the comfortable constant temperature of human body within 3 minutes. The heating will be stopped when the power is turned off.
- When you need to move around or stop heating, unplug the plug that connects the hot insoles. It is very convenient to use the same as ordinary shoes.
- If you leave for a long time, please be sure to unplug the power adapter to save energy and extend the service life of the product.
- This product can also be used with the charger. The output power of the charger should be greater than 5V/2A, otherwise the temperature will be a little lower.

WARNING

- Unplug the power when not in use to avoid prolonged heating.
- Old people and children need to use it under supervision.
- Do not wear electric warm insoles for strenuous exercise to protect heating chip.
- Hot insoles can be washed just like ordinary insoles. Do not dip in water for a long time. Be sure to dry them when you use them again.
- Different models of products with different technical parameters, accessories can not be universal, please do not mix and use.

*Power bank and power supply are not included in the kit.

CZ Vyhřívané vložky na USB napájení. Uživatelská příručka.

- Pokud je to třeba, vyjměte z bot původní vložky.
- Ořízněte vyhřívané vložky tak aby perfektně seděly do bot.
- Vložte vyhřívané vložky do boty.
- Připojte USB kabel vyvedený z vložek k powerbanky 5V.
- Vložky začnou hřát automaticky po připojení ke zdroji, resp. přestanou hřát po odpojení ze zdroje.

BEZPEČNOSTNÍ POKYNY

- Před použitím si přečtěte manuál a uschovejte si jej pro budoucí potřebu.
- Používejte pouze v souladu s manuálem.
- Neupravujte produkt (krom zkrácení vložek dle vzoru na spodní straně, pokud je nutné).
- Produkt sami neopravujte.
- O vhodnosti použití se poraďte s lékařem.
- Poškozený nebo opotřebený výrobek nepoužívejte.
- Nedoporučujeme vložky používat, pokud je okolní teplota více jak 30°C.
- Držte mimo zdroje tepla.
- Držte vložky mimo zdroje vody.
- Pokud je teplota příliš vysoká, okamžitě přestaňte vložky používat.
- Netahujte za kabely silou.

UPOZORNĚNÍ

- Nepoužíváme-li výrobek, odpojíme ho ze zdroje.
- Používáme pouze s odpovídajícím zdrojem elektriky.
- Z důvodu nebezpečí přehřátí vložky nepoužíváme při sportu.
- Nevhodné pro děti a starší lidi.
- Vložky se nesmí zahřívat déle než dvě hodiny.
- Učítíme-li pálení, vložky okamžitě přestaneme používat.

*Powerbanka a napájecí zdroj nejsou součástí sady.

