

Audew

Portable Tire Inflator
OWNER'S MANUAL

KEEP THE ORIGINAL BOX, PACKING AND RECEIPT. BEFORE OPERATING THIS UNIT, READ THE MANUAL THOROUGHLY AND RETAIN IT FOR FUTURE REFERENCE

Portable Tire Inflator

Technical Specifications

1. Input Voltage: Charger \geq 5V1A
2. Maximum Current: 5A
3. No-load Current: < 2A
4. Air Flow: 15L/min
5. Maximum Detection Pressure of Tire Pressure: 150 PSI
6. Length of Exposed hose: 13 \pm 0.5cm/5.1 \pm 0.20inch
7. Dimensions of the Product: 5.5*4.5*19.8cm/2.2*1.8*7.8 inch
8. Dimensions of the Package: 23.5*8.8*6.4cm/9.3*3.5*2.5 inch
9. Net Weight: 360g/0.8 lb
10. Gross Weight: 500g/1.1lb

Operating Instructions

1. Connected one end of the air hose to the air outlet of the inflator and tighten clockwise, connect the other end of the hose to the tire valve core and press the buckle.
2. Press the "UNIT" button to switch four different units: PSI, BAR, KPA, kg/cm².
3. The "+" and "-" buttons are used for setting pressure values. You could adjust pressure slowly by tapping the button, and you could adjust pressure quickly by pressing the button for a longer time.

When it comes to the desired pressure value, the value will flicker for 4 seconds and be set automatically, or you could press the "UNIT" to set it.

4. Press the "Power" button, and the inflator begins to pump up the tire. It will shut off automatically when the proper tire pressure is reached.

After the inflation, remove the end of the tire inflator from the air nozzle

Notice

To prevent overinflation of a tire, please refer to the recommended pressure value of the car's manual before the inflation. Or refer to the marking of a tire on your bicycle.

Precautions

1. Make sure the inflator is fully charged before the usage. It takes at least 4 hours for the first time to be fully charged, and at least 2 hours thereafter.
2. This production is designed for inflation occasionally. Prolonged usage will lead to overheating of the product, and may cause damage to it. It's better to cool it down for 8 minutes after continuously working for 8 minutes.
3. Please keep the product and its accessories away from the children.
4. The inflator and its accessories are not toys, so do not play with them and insert them into ears, noses or mouths of any people or animals.
5. Please do not use the inflator near the areas with inflammable, explosive liquids, or gases.

6. Please do not leave it alone while the inflator is pumping up, and you should take note on its working status.
7. If there is an abnormal noise or overheating of the production during the inflation, please power it off immediately and let it cool down for at least 15 minutes. As the hose is hot after the inflation, please be careful with your hand while removing it.
8. Please do not expose the inflator directly to the sunlight or the rain.
9. If you do not use the inflator for a long time, please keep it in a dry environment and out of the reach of children. It is recommended that the inflator should be charged once every six months.

Warning

For your and others' safety, please use the inflator and its accessories according to the operating instructions provided by the manufacturer. The method not mentioned in the instructions may cause danger.



www.audew.com

If you have any questions after receiving the products, please contact our customer service, and we will reply to you within 24 hours.